



Diamond Honing

Designed for Commercial Terrazzo Floors

Green Cleaning Compliant



Available on State Approved Coops



Bio-Shine is a Proud Supporter of Sustainable Jersey



Piranha Brand Diamond Honing

Benefits



1. **Long Term Shine** using Only Water - No Harsh Chemicals
2. **Green Cleaning Compliant System**
3. **Eliminate** Black Heel Marks, Scuff Marks, Yellowing, Etc.
4. **Reduce** long term labor and supply costs **Significantly**
5. **Improve** building appearance **Dramatically**
6. **Eliminate** Stripper, Sealer, Floor Finish, etc.

Piranha Brand Diamond Honing

Process

STEP 1 - PREPARE FLOOR SURFACE



Prepare the floor surface by removing all floor finish coatings and sealers using **Piranha Brand Zee Best No Odor Floor Stripper**. You must strip the Terrazzo floor down to it's bare surface.



For quicker results use the **Piranha Brand King Pro** propane machine for stripping and diamond cutting. This will significantly reduce the project time and yield tremendous results.

Important Note

It is always best to protect the walls with plastic to prevent unnecessary extra work.

Piranha Brand Diamond Honing

Process

STEP 2 - DIAMOND HONING RESIN DISKS



Using a Piranha Brand Diamond Honing Floor Machine and Diamond Resin Disks, scrub the floor using #50, #120, #220, and #400.

Important Note

Make sure you are moving North/South and East/West.
Make at least 8 passes - the more the better!



Using an autoscrubber will reduce the project time dramatically, thus saving valuable labor time.

Piranha Brand Diamond Honing

Process

STEP 3 - DIAMOND HONING POLISHING PADS



You will see the water is much cleaner during these stages.

At this point in the diamond honing process, you will use a conventional 175 RPM **Piranha Brand Diamond Honing Floor Machine** equipped with #800, #1500, #3000, and #8000 **Piranha Brand Diamond Honing Polishing Pads** using a liberal amount of water.

You will notice a shine when you complete the first polishing step, #800 grit. The shine will look progressively better as you advance through the process. In an effort to save time and money, you can stop at whichever pad creates your desired shine. You can always advance at a later date.

Important Note

You can use **Piranha Brand Diamond Polishing Pad #11000** for the highest gloss.

Piranha Brand Diamond Honing

Diamond Honing Polishing Pads / Resin Disks



14" x 28" Rectangular Pads


- BS123981 - 14" x 28" - 800 Grit - White - 2/cs
- BS123982 - 14" x 28" - 1500 Grit - Yellow - 2/cs
- BS123983 - 14" x 28" - 3000 Grit - Green - 2/cs
- BS123984 - 14" x 28" - 8000 Grit - Orange - 2/cs
- BS123985 - 14" x 28" - 11000 Grit - Purple - 2/cs

14" x 20" Rectangular Pads

- BS123902 - 14" x 20" - 800 Grit - White - 2/cs
- BS123903 - 14" x 20" - 1500 Grit - Yellow - 2/cs
- BS123904 - 14" x 20" - 3000 Grit - Green - 2/cs
- BS123905 - 14" x 20" - 8000 Grit - Orange - 2/cs
- BS123863 - 14" x 20" - 11000 Grit - Purple - 2/cs

20" Round Pads

- BS121302 - 20" - 800 Grit - White - 2/cs
- BS121304 - 20" - 1500 Grit - Yellow - 2/cs
- BS121299 - 20" - 3000 Grit - Green - 2/cs
- BS118013 - 20" - 8000 Grit - Orange - 2/cs
- BS118014 - 20" - 11000 Grit - Purple - 2/cs



4" Resin Disks

- BS128414 - 4" Diamond Honing Resin Disks 50 grit
- BS123901 - 4" Diamond Honing Resin Disks 120 grit
- BS123902 - 4" Diamond Honing Resin Disks 220 grit
- BS123903 - 4" Diamond Honing Resin Disks 400 grit



Piranha Brand Diamond Honing Equipment



BS120201

The **Piranha Brand Diamond Honing Floor Machine 20"** is designed for heavy duty use. Its sturdy frame has built in weight plates. You can easily strip floors or diamond hone using one machine.



BS119661

The **Piranha Brand HD Floor Machine 20"** has a 1.5 HP motor. You can strip floors or diamond hone using one machine.

Unicorn Style Weight Kit available
BS477040



BS128222

The **Piranha Brand King Pro Propane Machine** is designed for performance. Its built rugged for long term use and difficult projects. You can strip and diamond hone floors quickly and easily. The solution tank provides liquid onto the floor allowing faster movement. It has 3 rotating heads on a rotating plate with 330lbs of down pressure.



BS121862

The **Piranha Brand 14"x20" Oscillating Floor Machine** is rectangular and allows you to get detail work done along walls/edges. The 180lb frame and 1750rpm motor provide performance where it is needed. You can strip and diamond hone using one machine.

Accessories


- BS898204** - 4 Gallon Poly Solution Tank
- BS111923** - Diamond Honing Pad Driver 20"
- BS119199** - Standard Pad Driver 20"
- BS119198** - Splash Guard 20" with Lip

Special Note

Smaller Units Available Upon Request

Piranha Brand Diamond Honing

Stripping Pads



14" X 20" Rectangular Pads



- BS116550** - 14" x 20" Black Stripping Pads - 5/cs
- BS116859** - 14" x 20" Maroon Surface Prep Pads - 10/cs
- BS130175** - 14" x 20" Dominator Heavy Duty Strip Pads - 5/cs

14" X 28" Rectangular Pads

- BS469729** - 14" x 28" Black Stripping Pads - 5/cs
- BS469748** - 14" x 28" Maroon Surface Prep Pads - 10/cs
- BS132840** - 14" x 28" Dominator Heavy Duty Strip Pads - 5/cs

20" Round Pads


- BS1993** - 20" Black Stripping Pads - 5/cs
- BS116859** - 20" Maroon Surface Prep Pads - 10/cs
- BS2972** - 20" Dominator Heavy Duty Strip Pads - 5/cs



- BS132056** - Astroturf Pad for Cleaning Grouted Floors 20"
- BS130920** - Astroturf Pad for Cleaning Grouted Floors 14" x 20"
- BS134189** - Astroturf Pad for Cleaning Grouted Floors 14" x 20"

Piranha Brand Diamond Honing

Stripping Brushes & Drivers




BS114876 - Heavy Duty Black Poly Scrub Brush 20"

BS120208 - Heavy Duty Nylo-Grit Strip Brush 20"

BS111923 - 20" Diamond Honing Pad Driver

****Specialty Drivers Available Upon Request****



BS119199 - 20" Hook and Loop Pad Driver

BS477143 - 20" Permagrip Pad Driver

Piranha Brand Diamond Honing

Accessories



BS125858

Piranha Brand Peroxide Powered All Purpose Cleaner assists in removing residue created from the slurry and provides brightness to the floor.



BS128713

Piranha Brand Zee Best No Odor Floor Stripper is effective on removing a wide variety of floor coatings quickly and easily.



BS1065

Piranha Brand Foam Buster reduces foam build up in autoscrubbers/wet vac recovery tanks - extending the life of your vacuum motor.



BS3685

Expandable
Door Guard 22"- 40"



Stripping Shoes / Replacement Soles

BS118452 - 12.5-13.5 Shoe / **BS118450** Soles
BS116336 - 10.5-11.5 Shoe / **BS118449** Soles
BS116335 - 8.5-9.5 Shoe / **BS116337** Soles



BS119558

Double Bladed
Neoprene Moss 22"
Floor Squeegee

Requires:

BS3344 - 60" Tapered Wood Handle



BS898204

4 Gallon Poly
Solution Tank



BS477040

Unicorn Style Weight Kit
includes (4) 10lb weights and hardware



BS119198


20" Splash
Guard with Lip



Piranha Brand Diamond Honing

In Action

Beeler School - Evesham Twp Public School




A Brief List of Facilities Using the Piranha Brand Diamond Honing Floor Care Program

**Evesham Twp Public Schools / Randolph Board of Education
New Lisbon Development Center / Hunterdon Developmental Center
Brick Twp Public Schools / Neptune Board of Education
Medford Board of Education / Gloucester Board of Education
Camden Cty Tech School / Lenape Regional High School District**

An Extensive List is Available Upon Request

**If you would like more information or would like us to visit your facility,
Don't Delay, Call Today!**

Created by:



Distributor Contact Information:



**190 Summerhill Rd
Spotswood, NJ 08884
Phone: (732)-251-9506
Fax: (732)-251-9586
Website: www.Bio-Shine.com
Email: Info@Bio-Shine.com**